
3M[™] Quick Swab


Reminders for Use

For detailed WARNINGS, CAUTIONS, DISCLAIMER OF WARRANTIES / LIMITED REMEDY, LIMITATION OF 3M LIABILITY, STORAGE AND DISPOSAL information, and INSTRUCTIONS FOR USE see product's package insert.

Wet Swabbing Method




Remove the desired quantity of 3M[™] Quick Swabs from the resealable plastic bag. Label the swab.



At the sampling location, prepare the swab by holding it with the bulb end near your thumb. Bend the red snap valve at a 45° angle until you hear the valve break. This allows the letheen broth to flow into the tube end and wet the swab.




Squeeze the bulb of the swab to transfer all of the letheen broth to the tube end of the swab.




Twist and pull apart the bulb end of the swab from the tube end of the swab which contains the letheen broth.

Swabs from the resealable plastic bag. Label


the swab.




Hold the swab handle to make a 30° angle 5 with the surface. Rub the swab slowly and thoroughly over the desired surface area. Rub the swab three times over this surface, reversing direction between alternating strokes.




After sampling is complete, securely insert the b swab back into the swab tube and transport to the lab for inoculation. Plate the letheen broth swab solution as soon as possible. Go to step 7 of the Inoculation Methods Section.




Twist and pull apart the tube end of the swab from the bulb end of the swab which contains the letheen broth.



Hold the swab handle to make a 30° angle with the surface. Rub the swab slowly and thoroughly over desired surface area. Rub the swab three times over this surface, reversing direction between alternating strokes.




4 After sampling is complete, securely insert the swab back into the swab tube and transport to the lab for inoculation.



Prepare the swab by holding it with the bulb end near your thumb. Bend the red snap valve, at a 45° angle until you hear the valve break. This allows the letheen broth to flow into the tube end and wet the swab.


5




6 Squeeze the bulb of the swab to transfer all of the letheen broth into the tube end of the swab. Go to step 7 of the Inoculation Methods Section. Plate the letheen broth swab solution as soon as possible.

Inoculation Methods


1mL Procedure



In the lab, vigorously shake or vortex the swab for 10 seconds, to release bacteria from the swab tip.





8 Wring out the contents of the swab tip by pressing and twisting the swab against the wall of the tube.



Garefully pour the entire contents of the tube onto a 3M[™] Petrifilm[™] plate. Follow current industry standards for disposal.

Multi-mL Procedure





Remove the swab from the tube. Add 1-3 mLs of sterile diluent to the swab tube. Replace the swab in the tube. Complete steps 7 & 8 of the 1mL Inoculation Procedure.

Use your thumb to bend the swab tube at a 90° angle at the highest mark that has diluent above it. Pour off a 1mL aliquot onto a Petrifilm plate. Repeat until the entire sample is used. Follow current industry standards for disposal.

3

Refer to Petrifilm plate product package inserts for proper incubation and interpretation instructions.

For more product information, visit: www.3m.com/microbiology



3M Health Care Food Safety Department Europe, CEE, MEA Hammfelddamm 11 D - 41453 Neuss Tel. +49 (0)2131-14 3000 Fax: +49 (0)2131-14 4443 www.3m.com/microbiology

3M and Petrifilm are trademarks of the 3M company. Please recycle. Printed in Germany. © 3M 2010. All rights reserved. 1463-101-EU